


Mark 5™

www.devcon.com

System Components Instructions for Use

The Mark 5[™] Gun System Consists of: • Mark 5[™] Gun for 50 ml Cartridge

- 1:1 Plunger
- 2:1 Plunger
- 10:1 Plunger



Inserting the Cartridge

- 1. Push release latch A upward and push rack B with gear teeth down into the gun until it stops.
- 2. Open breech .
- 3. Insert cartridge into breech. Close breech to hold cartridge in place.
- 4. Turn cartridge cap **E** counter-clockwise and remove.
- 5. Carefully squeeze trigger until both sides of the cartridge are flowing freely.
- 6. Push on and turn mixer nozzle clockwise.
- 7. Cut tip of mix nozzle to desired bead size.

The Mark 5™ Gun is now ready for application.

Application

- 1. Before applying, prepare all surfaces to be bonded.
- 2. Squeeze the trigger, dispose of small amount of product as waste to ensure proper ratio.
- 3. Apply adhesive to the substrate surface.

After application, if cartridge is not completely empty, remove mix nozzle and replace cap .

A new mix nozzle is required for further application.

